SOPRASEAL® XPRESS G

WALLS



WATERPROOFING

AIR/VAPOUR BARRIER FACTORY-LAMINATED ON AN EXTERIOR GYPSUM BOARD

IDEAL FOR PROJECTS WITH TIGHT DEADLINES

SOPRASEAL XPRESS G decreases the number of installation steps by combining several products in one, increasing productivity on site. SOPRASEAL XPRESS G is an air and vapour barrier used on walls. It is factory-laminated with modified bitumen adhesive on an exterior gypsum board with surfaces free from organic fibers (paper free).

- First ABAA-evaluated assembly
  (Factory-bonded membrane to sheathing)
- Fewer installation steps
- Perfect solution for a flameless installation at low temperature
- Self-sealing screws

COMPLEMENTARY PRODUCTS

SOPRASEAL STICK PRIMER & ELASTOCOL STICK ZERO
Used to prepare surfaces before the installation of self-adhesive membranes to seal the joints between panels.

SOPRASEAL STICK FLASHPRO
SOPRASEAL STICK FLASHPRO HT
SOPRASEAL STICK 1100T in cut rolls

SOPRASEAL STICK 600 TC in cut rolls
Self-adhesive air/vapour barrier membrane composed of a tri-layer laminated polypropylene facer.

SOPRASEAL XPRESS G	
THICKNESS	Membrane : 0.15 mm (6 mil) Panel : 12.7 mm (1/2 in)
DIMENSIONS	1.2 x 2.44 m (4 x 8 ft)
SURFACE	Tri-laminated woven polyethylene
UNDERFACE	Gypsum
BITUMEN	SBS modified

INSTALLATION INSTRUCTIONS

1

Install SOPRASEAL XPRESS G panels horizontally on studs.

2

Secure panels using SOPRASEAL XPRESS G SCREWS.

3

Soak all surfaces that will receive the self-adhesive membrane with SOPRASEAL STICK PRIMER to seal the joints between panels.

4

Cover all panel joints with SOPRASEAL STICK 1100T or SOPRASEAL STICK 600 TC membrane in cut rolls of 150 mm (6 in).

5

Complete the application by passing a smoothing roller on membrane strips to ensure perfect adhesion.

6



The installation is completed.

If you have any questions about this product or its installation, please contact your SOPREMA representative.

BR154_v.112019